

**Aisin AW 55-50SN, 55-51SN,
TF-60SN, TF-80SC, TF-81SC, TR-60SN;
Mini 6F21WA; VW/Audi 09D, 09G, 09K, 09M**

**Solenoid Wire
Connector Retainer**

Part No.

59947-60

Solenoid Wire Connector Retainers (3)

Patent No. 9,048,595

NOTE: Also fits AF 23/33, RE5F22A,
Volvo (AM6), Opel (AF40), Peugeot (TF80),
Saab (AF40/6), Land Rover (TF80),
Ford (AF21), Mazda (AW6A-EL).



Installation

1. Plug the valve body wiring connector into the solenoid connector (**Figure 1**).
2. Clip Sonnax wire connector retainer over the two adjoining connectors (**Figure 2**):
 - a. Place the Sonnax retainer edge (A) under the solenoid connector.
 - b. Place the Sonnax retainer edge (B) flush and tight with the back of the solenoid connector.
3. Once these positions have been located, roll the Sonnax wire connector retainer (C **Figure 2**) until the short leg snaps into place over both adjoining connectors (**Figure 3**).

